

Fruit

Home / Kitchenwares / Stainless Steel Kitchen Tools / Corer

Fruit Corer

Stainless Steel Kitchen Tools

Item No.: KW30052




Description

Quotation Information









SIZE



Note: Size is subject to actual sample.

DETAILS

The putter is easy to push out the core and easier to clean



Sharp wavy serrated incision, easier to insert the fruit and take out the core.



ABS handle, fit the palm, comfortable to grip



USE

Instruction for use:

Aim the corer at the core of the fruit, rotate and insert it to the bottom, gently pull out the corer and push the rod out of the core.

